



Gravel or Groundwater Mix

Any size hole use SureFlow Sand and Bentonite

Not Reclaiming – Add a minimum of 2 ½ bags of bentonite per 500 gallons. Then add the appropriate size pail of SureFlow Sand based on your mix tank size.



SureFlow Sand is pre-measured for 500, 750, or 1000-gallon tanks.

Reclaiming – Add 6 bags of bentonite and 1 bag of SureFlow Sand. Repeat until desired funnel viscosity is achieved. We recommend a minimum of 120 sec/qt funnel viscosity drilling gravel or groundwater.

