



# Gravel or Groundwater Mix

## Any size hole use SureFlow and Bentonite

**Not Reclaiming** – Add a minimum of 2 ½ bags of bentonite per 500 gallons. Then add the appropriate size pail of SureFlow based on your mix tank size. If clay is an issue add appropriate amount of SureFlow Clay per label.



SureFlow Sand is pre-measured for 500, 750, or 1000-gallon tanks.

**Reclaiming** – Add 6 bags of bentonite and 1 bag of SureFlow. Repeat until desired funnel viscosity is achieved. We recommend a minimum of 120 sec/qt funnel viscosity drilling gravel or groundwater. If clay is an issue add appropriate amount of SureFlow Clay per label.

